




E2351 SHOWER DOOR MAINTENANCE

E2351 (CURVED) SHOWER DOOR ONGOING MAINTENANCE AND CHECKS

- Shower door hardware should be inspected frequently and adjusted quarterly.
- Ensure all floor guides and wall bumpers are present and secured. Immediately replace any missing guide or stopper hardware. (Email requests for additional parts can be sent to info@mgrouppcorp.com)

PROCEDURE

1. Moving components may shift out of alignment and require regular maintenance.
 - a. Ensure the glass door remains vertical and operates correctly.



- b. If misaligned, use a screwdriver to adjust the screws beneath the upper wheel:
- Raise or lower the glass to achieve a vertical position.
 - Confirm smooth operation.

